

Mirrored One-Way Daytime Privacy: Inside Application

Application and Cleaning Instructions

1. Preparation

- Clean the glass with mild soapy water* removing any dust, paint specs, grease or other contaminants.
- Complete a second cleaning if necessary and then rinse off with water only
- Thoroughly dry the surface before application
- Apply the film in temperatures between 3°C (35°F) and 30°C (90°F)
- Cut the film to the window size. Allow 20mm of excess material on all edges which can be trimmed later
- Use a spray bottle to apply a covering of water mixed with 2 drops of dish washing detergent
- Place your film on a flat surface. Carefully peel off the backing film. The film is very thin and care must be taken not to crease. Stick some tape on either side of a corner and peel the tape apart to start the process
- Spray the exposed (adhesive) surface of the film with the water/detergent. Lightly spray your hands to stop the film sticking to them



2. Application

- Carefully pick up the film and slide into position on your glass. Keep the film smooth. It will continue to move, providing the glass is wet. Reapply water if necessary
- Spray the film surface with application fluid, which will wash any dust that might scratch the surface and will help to avoid scratching the surface with the squeegee



3. Remove air bubbles and trim

- Use the plastic squeegee provided** smooth out the film, handling the material with care. Begin from the centre and work outwards in all directions. Ensure that no bubbles are trapped, especially at the edges
- As a last resort, remove any stubborn bubbles by gently popping them with a pin and rubbing
- Wipe away excess water. There may be some water marks left on the film, however this will dry/ evaporate over time
- To trim: Position the blade on the edge of the squeegee. Run the squeegee and the blade around the edges of the frame. Leave a 1-2mm gap around the edges to ensure reliable edge adhesion



4. Cleaning and Aftercare

- Do not wash the film for 24 hours after application to allow the adhesive enough time to work
- Clean with a mild soapy solution using a sponge or microfibre cloth. Do not use abrasive cloths or solvent cleaners



* Do not use window cleaning spray, as it can damage the film!

** Squeegee not included with samples

